



# 2018+ (JL/JLU/JLR/JLUR) Jeep Wrangler Yeti XD Stabilizer Relocation Bracket Installation Instructions

*Stabilizer Relocation Bracket Number: 79029001*



## Tool List:

1. Center Punch
  2. 15mm socket and ratchet
  3. 18mm socket and ratchet
  4. 18mm open end wrench
  5. 22mm open end wrench
  6. Power Drill / Hammer Drill
  7. Sharp Drill bits – final hole size is 13/32
  8. Needle Nose Channel Locks (*optional for tightening m10 nut*)
  9. Torque Wrench with 15mm and 18mm socket
- 

## Installation Steps:

1. You can either unbolt the draglink and tie rod nuts on the passenger side knuckle and move them out of the way, or, you should be able to turn the wheel full passenger and have enough room to finish the install.
2. Remove Track Bar Bolt and nut (axle side)



3. Use new M14 fastener and nut and loosely tighten down Stabilizer Relocation Bracket



4. Line up/level stabilizer bracket and use center punch to mark center of where you want to start drilling
5. Start with a small drill bit and begin drilling pilot hole



- Progressively increase the Drill bit size, finishing the hole with a 13/32 (or similar) Drill Bit



- Install new M10 Bolt and Nut where you just finished drilling the hole (use vice grips on nut if needed)



- Torque down M10 Bolt and Nut to: **40-45 ft. lbs**
- Torque down M14 Track Bar Bolt to: **125-130 ft. lbs.**
- Install Stabilizer